

UTILITY KNOB Use Instructions

1. Install Utility LockTM (threaded stud) following instructions 1-4 under Utility LockTM.
2. Thread the locking knob onto the threaded stud, securing your item.

Example: Place wheel chock bracket (with hole) onto the threaded stud, then thread the locking knob onto the threaded stud, securing the wheel chock to CORE-Trax.

NOTES: Loads shift & settle; inspect after 10 miles; then every 40/50 miles thereafter (inspect in shorter intervals if on rough bumpy roads or inclement weather). Make sure all connecting points on vehicle are secure.

WARNING: Inspect product before each use. **DO NOT USE:** If product is deformed, worn, damaged, rusted or not securely installed. Avoid contact with sharp objects, flame or chemicals that may damage or weaken product, as these conditions may result in severe **DAMAGE** to persons or property. Product is **NOT** designed nor to be used as a personal restraint, or towing device. **USER** assumes full responsible for determining product's safe condition and suitability for a particular purpose. **NOTICE TO PURCHASER:** Core Products USA is not responsible for damage or injury caused by improper use of products.

COETM
Products USA