

## **POCKET TIE DOWNS Install Instructions**

1. Partially thread the wing nut onto the 3/8" stud (with wings pointed upward).
2. Squeeze wings together and place into stake pocket or other opening.
3. Line up black rectangular base with stake pocket or opening.
4. With one hand on the tie down and another on the plate; begin turning the tie down (top) clockwise until snug. Place a rod or screwdriver through eye of tie down and complete tightening/cinching down; being sure not to over tighten. Check tie down installation by pulling on the tie down to be sure shifting has not occurred. If tie down has shifted, loosen (by turning counter clockwise) and re-installing.

**NOTES:** Loads shift & settle; inspect after 10 miles; then every 40/50 miles thereafter (inspect in shorter intervals if on rough bumpy roads or inclement weather). Make sure all connecting points on vehicle are secure.

**WARNING:** Inspect product before each use. **DO NOT USE:** If product is deformed, worn, damaged, rusted or not securely installed. Avoid contact with sharp objects, flame or chemicals that may damage or weaken product, as these conditions may result in severe **DAMAGE** to persons or property. Product is **NOT** designed nor to be used as a personal restraint, or towing device. USER assumes full responsible for determining product's safe condition and suitability for a particular purpose. **NOTICE TO PURCHASER:** Core Products USA is not responsible for damage or injury caused by improper use of products.