

## RATCHET STRAP Use Instructions

1. Attach both S-hooks to secure anchoring points/tie downs. Note: Hooks, hardware and webbing strap should be in-line for maximum performance.
2. Pull on strap (loop end) until most of the slack is removed.
3. Pump ratchet handle until desired tension on strap is achieved. Wind three or more layers of webbing strap around reel to secure.
4. After cargo is secure, move Ratchet handle down flat (closed position) for transit.
5. To release, press "Easy-Grip thumb tab" and lift Ratchet handle (open position) 180 degrees to loosen strap for adjusting and removal.

**NOTES:** Webbing strap jam will occur if Ratchet is used to take up excess slack. If this happens simply unwind strap from around Ratchet reel and start procedure over, first removing most of the slack from strap (step 2). Loads shift & settle; inspect after 10 miles; then every 40/50 miles thereafter (inspect in shorter intervals if on rough bumpy roads, or off road). Make sure all connecting points on vehicle are secure.

**WARNING:** Inspect product before each use. **DO NOT USE:** If product is deformed, worn, damaged, rusted or not securely installed. Avoid contact with sharp objects, flame or chemicals that may damage or weaken product, as these conditions may result in severe **DAMAGE** to persons or property. Product is **NOT** designed nor to be used as a personal restraint, or towing device. **USER** assumes full responsible for determining product's safe condition and suitability for a particular purpose. **NOTICE TO PURCHASER:** Core Products USA is not responsible for damage or injury caused by improper use of products.