

JR. MAXX™ CARGO BAR Use Instructions

Placing Cargo Bar in place:

1. Pack load flush against bulkhead of vehicle cargo area (Truck/Trailer, Truck bed, Van, etc.).
2. Position Cargo Bar against end of load and hold horizontal at a level even with a reinforced section of the vehicle (i.e. truck bed sides).
3. Be sure to place Cargo Bar at the level/balance of the load.
4. Depress quick release lever and lift ratchet handle to unlock.
5. Pull/slide end foot until the Cargo-Bar reaches end-to-end (touching walls), back foot away from wall about one/two inches; lift handle and begin ratcheting process.

CAUTION: DO NOT over tighten Cargo Bar or use on single skinned walls as this may result in DAMAGE to vehicle.

6. Return the handle to the down position until locked.

Removal:

1. Depress quick release lever and lift ratchet handle to unlock/remove.
2. The Cargo Bar can now be loosened and removed.

NOTE: Loads shift & settle; inspect after 10 miles; then every 40/50 miles thereafter (inspect in shorter intervals if on rough bumpy roads, or off road).

WARNING: Inspect product before each use. DO NOT USE: If product is deformed, worn, damaged, rusted or not securely installed. Avoid contact with sharp objects, flame or chemicals that may damage or weaken product, as these conditions may result in severe DAMAGE to persons or property. Product is NOT designed nor to be used as a personal restraint, or towing device. USER assumes full responsible for determining product's safe condition and suitability for a particular purpose. **NOTICE TO PURCHASER:** Core Products USA is not responsible for damage or injury caused by improper use of products.